



Installing a feather edge fence

1. Clear the area: Remove any old fencing or vegetation.
2. Mark the fence line: Use stakes and string to mark the perimeter of the fence.
3. Dig post holes: Dig holes that are 600mm deep & Roughly 1800mm apart from each other. Make sure you double check your measurements so your rails fit correctly.
4. Secure the posts: Use struts to hold the posts in place and a spirit level to ensure the post is level, then fill the holes with concrete or post mix. Allow adequate time for your post mix or concrete to set before continuing any work (we recommend following the suppliers instructions.)
5. Install the rails: Cut the rails to size if needed, then attach them to the front of the posts using 4 x 3" wood screws per rail. Make sure you evenly space each rail from top to bottom for extra strength. If you have purchased an extension kit from us, leave enough room for your next rail to attach to the post parallel with the first section.
6. Attach the feather edge boards: Overlap the boards by no more than 25mm to ensure maximum coverage. Using the 40mm nails, hammer in 2 nails per fence rail. Fix each board fully before moving onto the next and use a spirit level to check your work as you go to ensure your boards run level.

Tips

- If you are not confident installing this product please seek advice from a qualified tradesman.
- Use a spirit level to ensure the posts are upright and the fence line is level.
- Use a spacer to maintain consistent spacing on the featheredge boarding.